



\* SOME PARTS  
ARE NO  
LONGER AVAILABLE





210002N


RESTRICTIVE TRIGGER





210001N

BOTTOM-FIRE TRIGGER





H: 1/4 in. 11.09 mm  
 J: .074 in. 1.87 mm  
 K: .067 in. 1.70 mm  
 L: 1 1/2 in. — 2 1/2 in. 38 mm — 63 mm



#### M4 REPLACEMENT PARTS

PART #	DESCRIPTION	PART #	DESCRIPTION	PART #	DESCRIPTION
AA0027	MAIN BODY ASSY.	GB0106	FEEDER SPRING ROLLER	KB2731	WASHER
AA0046	DETENT ASSY.	GB0107	SPRING RETAINER	KB2733	WASHER
AB0029	DETENT	GB0108	REAR BRACKET	KB2734	WASHER
BA0073	CYLINDER CAP ASSY.	GB0109	UPPER STAPLE HOUSING	KB3052	SPIROL PIN
BA0074	EXHAUST VALVE ASSY.	HB0044	INNER TRIGGER (RESTRICTIVE)	KB3053	SPIROL PIN
BA0075	FIRING VALVE PISTON ASSY.	HB0055	LABEL (SAFETY PRECAUTIONS)	KB4033	SPRING
BA0076	CYLINDER CAP ASSY.	HB0060	SAFETY	KB5005	SPRING
BA0078	CYLINDER SLEEVE ASSY.	HB0061	SAFETY LINK	KB5138	VALVE SPRING
BB0057	EXHAUST DEFLECTOR	HB0062	ADJUSTOR	KB5139	DETENT SCREW
BB0072	PLATE	HB0063	RETAINING SPRING	KB5140	FEEDER SPRING
BB0073	PISTON STOP	HB0064	TRIGGER COVER	KB5156	SCREW
CA0058	HOUSING	HB0075	INNER TRIGGER	KB5266	SPRING (RESTRICTIVE)
CA0059	HOUSING	HB0127	LABEL (SAFETY PRECAUTIONS)	LB0014	SEAL
CA0060	VALVE CORE	HB0183	TRIGGER	LB0015	SEAL
CB0010	VALVE CAGE INSERT	KA0003	DRIVER PIN ASSY.	LB0016	SEAL
EA0033	PISTON ASSY.	KB0016	SCREW	LB0019	SEAL
EB0196	DRIVER (1/4" CSK.)	KB0043	SCREW	LB0022	SEAL
EB0198	DRIVER (3/4" CSK.)	KB0045	SCREW	LB0024	SEAL
FA0118	BACKPLATE	KB0067	SCREW	LB0036	SEAL
FB0043	BRACER SPRING	KB0156	SCREW	LB0044	SEAL
FC0049	BACK UP SPRING	KB0645	SET SCREW	LB0083	SEAL
FC0050	RIGHT LOCKING BLOCK	KB1495	HEX NUT	LB0086	SEAL
FC0052	GATE	KB1544	SPRING PIN	LB0089	SEAL
FC0055	ADJUSTING BLOCK	KB1553	SPRING PIN	LB0093	SEAL
FC0059	LEFT LOCKING BLOCK	KB1568	SPRING PIN	LB0118	SEAL
FH0001	LOCK ASSY.	KB2011	SHOULDER SCREW	LB0131	SEAL
GA0213	BACK UP PLATE	KB2403	DOWEL PIN	LB0137	SEAL
GA0214	MAGAZINE RAIL	KB2704	LOCK WASHER	LB0768	SEAL
GA0215	FEEDER CLIP			LB3499	SEAL